

Air Cushion Speaker

User's Guide for Model ISBW101 v2682-01




Features

- Waterproof
- Shock absorbing cover
- Bluetooth wireless 5.0: range 60 ft. (18m)
- Party Plus Mode
- Built-in rechargeable battery: approximately 18hrs playtime at 50% volume
- USB-C port for battery recharge

Includes

- USB-C to USB charging cable
- User manual
- Wrist Strap

Overview




1. **Micro SD Port**
2. **Aux In**
3. **DC Power Input**
4. **Charging/Bluetooth Indicator LED:** Light will turn solid red when charging and will turn off when fully charged. Flashing blue when in Bluetooth mode. Solid Blue light when paired to a device.
5. **Power/Source:** Press and hold to power ON/OFF. Press to change sources between Bluetooth, Aux in and SD modes.
6. **Play/Pause:** Press to play/pause audio. When powered ON, quickly press twice to pair to enter into pairing mode. Press and hold to activate **Party Plus** mode.
7. **Volume/Skip+/Prev- :** Press to adjust volume level. Press and hold to change to previous/next track.
8. **LED Lights:** When first powered ON repeatedly press to change flashing speed (once for slow, twice for medium, three times for fast). Continually press to change the lights to a specific color (white, blue, red, green, yellow, purple, light blue and OFF).

Battery Charging

To charge the internal battery, plug the USB charging cable into the DC Power Input on the speaker and a powered on computer or USB power adapter (not included) and standard power outlet. Charging time is approximately 4 hours. Battery life is approximately 18 hours at 50% volume.

While the unit is charging it will display a solid red light. When the battery is fully charged the light will turn off.




Aux In & Micro SD

Aux In


Requires a 3.5mm audio cable (included).

1. Connect a 3.5mm audio cable to the **Aux In** on the unit and the **audio output** on an audio device. The unit will automatically change to Aux in mode.
2. Use the controls on the connected device to select and play audio. Be sure the volume on your connected device is audible when you begin playing.



Micro SD

1. Load a Micro SD memory card into the Micro SD port.
2. The speaker will automatically switch to SD mode.
3. Use the controls on the speaker to select and play audio from the connected drive.



Party Plus Mode

If you have another ISBW101 speakers, you can pair and play the two speakers together for a surround sound effect, or have two speakers playing in different rooms.

1. To enter Party Plus Mode, Power ON both speakers and make sure both units are in Bluetooth mode.
2. Press and hold the **Play/Pause** button on one of the units (this is now the primary unit), and the speakers will attempt to pair to each other.
3. When the two speakers are paired together a beep will announce the connection.
4. Connect Bluetooth device to speakers using the steps from the “**Pairing and Playing Bluetooth Audio**” section below.
5. Use your device to select and play tracks. The audio will now be heard through both speakers.
6. To disconnect the speakers, press and hold the **Play/Pause** button on any one of the two units.

Note: To use Party Plus Mode, please make sure that you connect the speakers before pairing to your Bluetooth device. You will not be able to connect the speakers if you are already paired to a Bluetooth device.

Pairing & Playing Bluetooth Audio

1. When first powered on, the speaker defaults to Bluetooth Mode and is ready to pair automatically. When pairing, remain within 3 feet of the Bluetooth device.
2. Using the controls on your Bluetooth device, select **ISBW101** in the Bluetooth settings to pair. *If need be, refer to the user's manual for your specific device for more information.*
3. When successfully paired, a voice prompt will announce the connection. Your Bluetooth device will now be heard through the speaker.
4. Use the controls on the connected Bluetooth device to select and play audio. Use the speaker controls or the connected Bluetooth device to play, pause, and adjust the volume level.
5. After initial pairing, the speaker will automatically connect to the last Bluetooth device used whenever it is in Bluetooth Mode. **Note:** If your device should become unpaired or you find it is unable to connect, Quickly press the **Play/Pause** button twice to enter into Pairing Mode. A voice prompt will announce the connection and you can connect to the speaker manually.

Customer Support

Customer Service: 1-888-999-4215 | **Email Support:** prodinfo@dpiinc.com | **Email Parts:** partsinfo@dpiinc.com

For Warranty Information and the most up-to-date version of this User's Guide, go to www.iLiveElectronics.com

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: www.iLiveElectronics.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: www.iLiveElectronics.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: www.iLiveElectronics.com



Copyright © 2020 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.

FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Additional Warnings

- **WARNING:** To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- **WARNING :** Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.
- Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of according to state and local guidelines. They should never be disposed of in normal household waste, and they should never be incinerated, as they might explode. Contact your local government for disposal or recycling practices in your area.



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. This product meets and complies with required Federal product guidelines.