

IPX5 Rating

This speaker features IPX5 level waterproof protection. This speaker can withstand low pressure water exposure from any angle. The speaker is not completely waterproof and should not be submerged in water. The speaker can withstand exposure to rain, but for the best results, avoid prolonged exposure to heavy, pooling rain.

IPX5 protection also does not offer protection from dust or dirt.

Notes

- A low battery alert will sound before the speaker battery runs out.
- If the speaker is not connected to Bluetooth within 5 minutes of powering on, it will power off to conserve battery.

FCC WARNINGS

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ADDITIONAL WARNINGS

- **WARNING:** To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- **WARNING :** Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.
- Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of according to state and local guidelines. They should never be disposed of in normal household waste and they should never be incinerated, as they might explode. Contact your local government for disposal or recycling practices in your area.



WARNING: Risk of cancer and reproductive harm from exposure to DEHP.

See www.P65Warnings.ca.gov

International Support

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at:
www.iLiveElectronics.com

Para descargar este Manual del Usuario en Inglés, Español y Francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en:
www.iLiveElectronics.com

Pour télécharger ce guide de l'utilisateur en Anglais, Espagnol ou Français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur:
www.iLiveElectronics.com

Contact Information

Website: www.iLiveElectronics.com

Email Support: proinfo@dpiinc.com

Email Parts: partsinfo@dpiinc.com

Phone Support: 1-888-999-4215

Warranty

For Warranty Information and the most up-to-date version of this User's Guide, go to:
www.iLiveElectronics.com.



***Protect for Today
Sustain for Tomorrow***

Specifications are subject to change without notice.

Copyright © 2026 Digital Products International (DPI, Inc.)

All other trademarks appearing herein are the property of their respective owners.

ILIVE™
ELECTRONICS



Magnetic Wireless Speaker

User's Guide for Model ISBW36B v3510-01


Features

- Bluetooth 6.0
- Magnetic back
- IPX5 rating
- Rechargeable battery
- Playback at 50% volume: up to 6 hours
- Playback at 100% volume: up to 2 hours

Includes


- USB-C to USB charging cable
- User’s guide

Overview & Controls



1. **USB-C Charging Port**
2. **Power/Play/Pause:**
Press to pause or resume playback.
Press and hold to power on/off.
Press two times to manually pair Bluetooth.
3. **Call Button:**
Press to answer an incoming call or end a call.
Press and hold to reject an incoming call.
Press two times to redial.
Press and hold for 5 seconds to turn voice prompts on/off.


Overview & Controls



4. **Speaker**
5. **LED Indicator**

Battery Power

- Charge fully before use. For best results, charge when the speaker is off. The charge time is approximately 1.5 hours.
- Using a **USB-C to USB** cable (included), connect the DC power input on the speaker to the USB port of a powered-on computer or USB power adaptor (not included) to charge the speaker.
- While charging, the LED will display a solid red light. When finished charging, the LED will turn off.



Pairing Bluetooth & Playing Audio

Note: This model features automatic Bluetooth pairing.

1. Power on the speaker, a voice will announce “Bluetooth,” when the unit is ready to pair. The LED Indicator will flash blue. *When pairing, remain within 3 feet of the unit.*
2. Using the controls on your Bluetooth device, select **ISB36** in the Bluetooth Settings to pair. A voice will announce “Bluetooth connected” when the speaker is successfully paired to your device. The LED Indicator will display a solid blue light. *If need be, refer to the user’s manual for your specific device for more information.*
3. Use the controls on the connected Bluetooth device to select tracks, play, pause, etc.

Note: This model will automatically pair to the last paired device when turned on. To pair to another device, press the **Power/Play/Pause** button two times to manually enter pairing mode.

Magnetic Back

This speaker features a clip and a strong magnetic back for more handsfree use. The magnetic back can attach to surfaces such as golf carts, refrigerators, metallic workbenches, and more.

