


Quickstart Guide




Power



Plug the small end of the power cord into the DC Input on the back of the speaker, and the large plug into a standard wall outlet.

Remote Batteries



Remote control: requires 2 AAA batteries (included).

Pairing a Bluetooth Device for the First Time

1. Power on the unit by pressing the **Power** button.
2. Press the  button on the remote to switch to **Bluetooth Mode**, indicated by a slowly flashing blue light.
*You can also press the **Source** button on the side of the unit.*
3. Press and hold the **Pair** button on the side of the unit.
The pairing indicator will flash blue quickly. When pairing, remain within 3 feet of the unit.
4. Use the controls on your Bluetooth device to select **ITB196** in your Bluetooth settings to pair.
If your device requests a password, enter the default password **0000**.
Refer to the user's manual for your specific device for instructions on pairing and connecting Bluetooth devices.
5. When successfully paired and connected, a beep will issue from the unit and the **Pairing Indicator** will display a solid blue light.
After initial pairing, the unit will stay paired unless unpaired manually by the user or erased due to a reset of the device. If your device should become unpaired or you find it is unable to connect, repeat the above steps.


Indicator Lights

STATUS	INDICATOR
Power Off	Red Light
Optical Mode	Amber Light
Aux In Mode	White Light
Line In Mode	Green Light
Bluetooth Pairing	Flashing Blue Light
Bluetooth Connected	Blue Light

Quickstart Guide



CONNECTING TO A TV



CONNECTING TO A DVD PLAYER, GAMING CONSOLE, OR OTHER DEVICE

