


- WARNING: Potential poking hazard, keep both antennae away from face and eyes.
- WARNING: To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- Battery shall not be exposed to excessive heat such as sunshine, fire, or the like.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Do not mix old and new batteries. Completely replace all old batteries with new ones.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.
- Batteries should be recycled or disposed of as per state and local guidelines.
- This product meets and complies with all Federal regulations.

**WARNING :** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).


## Features / Includes

- Remote with built-in charging cable
- Remote range - 10 ft.
- LED headlights & tail lights
- 4 Road cones for obstacle and precision driving practice
- Built-in rechargeable NiMH battery
- Operating time - 6-8 minutes
- Charge time - approx. 5 minutes


## Remote Control



## Overview




## Remote Batteries



## Opening & Undocking the Car


Open the can by gently pulling the top of the can upwards. Detach the car from the remote control by pressing and holding the **Release Button** and gently sliding the car to the right until it is clear of the dock on the remote.



## Charging the Car

Before charging, make sure the remote has working batteries. Initial charge time is approximately 5 minutes. Charge fully before use.

- Flip out the charging cable from the body of the remote and **connect the plug to the DC charging port** on the underside of the car. While charging, the **Charge Indicator** will light up green, and turn off when charging is complete.




## Driving

- Use the controls to move the car forwards and backwards, and steer left or right.
- Extend the antenna for increased control distance. When driving, the Signal Indicator will light up, indicating that the car and remote are connected and receiving control inputs.




Forward/Reverse



Steer Left/Right

## Adjusting Steering

The car may show a tendency to pull to one direction while driving. Use the dial on the underside of the car, between the front wheels, to counter this effect and drive straight.



## Contact Information

**Website:** [www.gpx.com](http://www.gpx.com)

**Email Support:** [prodinfo@dpiinc.com](mailto:prodinfo@dpiinc.com)

**Email Parts:** [partinfo@dpiinc.com](mailto:partinfo@dpiinc.com)

**Phone Support:** 1-888-999-4215



Copyright © 2016 Digital Products International (DPI, Inc.)  
All other trademarks appearing herein are the property of their respective owners.  
Specifications are subject to change without notice.

## Warranty

For Warranty Information and the most up-to-date version of this User's Guide, go to:  
[www.gpx.com](http://www.gpx.com).

## International Support

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: [www.gpx.com](http://www.gpx.com)

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: [www.gpx.com](http://www.gpx.com)

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: [www.gpx.com](http://www.gpx.com)



**RC Car in a Can**

User's Guide for Model DC06-1524-01

